


## Extended Stop Arm Control Switch



When Bus Ignition is on the red LED light Indicating Stop Arm Is lit all the time

When Switch is pushed **ON** the Green Light will go on. This indicates that the stop arm will work with the short arm